



**FITTING INSTRUCTIONS FOR FP0089BK FORK PROTECTORS
BMW F800GS 08'-**



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

- Undo front left spindle bolt. Remove and replace with R&G supplied bolt
- Torque to recommended torque setting
- Take one of the protectors with the recess on the back and position over bolt head
- Slide bar through the bobbin and wheel spindle
- Bar should sit equal length each side
- Place spacer onto exposed end of bar and then slide remaining protector onto bar
- Take the two washers and put one over each end of the bar
- Take the two nyloc nuts supplied and put one on each end of the bar
- Tighten the assembly - Do not overtighten – the nyloc nuts will hold it tight.