



FITTING INSTRUCTIONS FOR BLP0002BK REAR FOOTREST BLANKING
PLATE
BMW S1000RR 2010 RIGHT AND LEFT HAND SIDES



THIS KIT CONTAINS THE ITEMS PICTURED AND LABELLED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)

M8x20mm LONG
COUNTER-SUNK
BOLT (x1)

M8x20mm LONG
COUNTER-SUNK
BOLT (x1)

LEFT HAND
SIDE



BLANKING-PLATE
(BLP0002) (x1)



M8x20mm LONG
COUNTER-SUNK
BOLT (x1)

M8x20mm LONG
COUNTER-SUNK
BOLT (x1)

**RIGHT HAND
SIDE**



BLANKING-PLATE
(BLP0002) (x1)

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt –
the rubber washers should be thrown away!

TOOLS REQUIRED

- 5mm metric Allen key.
- T45 Torx key.

Left-hand side (as you sit on bike)

- Using T45 Torx key remove the two bolts and remove rear footrest.
- Fit two of the counter sunk headed bolts through the blanking plate so head sits in counter-sink.
- Offer assembly up to bike and engage both bolts.
- Tighten evenly using 5mm Allen key.

Right-hand side (as you sit on bike)

- Using T45 Torx key remove the two bolts and remove rear footrest.
- Fit two of the counter sunk headed bolts through the blanking plate so head sits in counter-sink.
- Offer assembly up to bike and engage both bolts.
- Tighten evenly using 5mm Allen key.