



FITTING INSTRUCTIONS FOR FP0053BK FORK PROTECTORS BMW R1200GS & BMW R1200S



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

- Place aluminium spacers into front fork spindle (will only fit one way)
- Place either bobbin (both the same) against out side of spacers (flat face)
- Push bar through
- Slide washers onto exposed ends of the bar.
- Attach nyloc nuts (supplied) to each end of the bar.
- Tighten until it locks up. Do not overtighten – the nyloc nuts will hold it tight.