



**FITTING INSTRUCTIONS FOR FP0057BK FORK PROTECTORS
BMW F800S & F800ST '06**

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

- Place smaller spigot of aluminium spacers into front fork spindle (will only fit one way)
- Place either bobbin (both the same) over out side of spacers (25mm dia)
- Push bar through
- Slide washers onto exposed ends of the bar.
- Attach nyloc nuts (supplied) to each end of the bar.
- Tighten until it locks up. Do not overtighten – the nyloc nuts will hold it tight.