



**FITTING INSTRUCTIONS FOR FP0058BK FORK PROTECTORS  
BMW HP2 06'**

**Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike**

- Remove the OEM bolt from LHS of spindle and replace with R&G bolt.
- Push bar through.
- Fit bobbins to either end of the bar, note the bobbin with the small counterbore goes on the LHS .
- Slide washers onto exposed ends of the bar.
- Attach nyloc nuts (supplied) to each end of the bar.
- Tighten until it locks up. Do not overtighten – the nyloc nuts will hold it tight.