



Installation

Model specific instructions

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

For:

- **Kawasaki VN1700 Vulcan**
(2009 - up)
- All VN1700 versions:
 - Standard
 - Custom
 - Classic
 - Classic Tourer
 - Voyager
 - Nomad
 - Etc.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Lift the fuel tank to access the AIT sensor in the air box..
- The AIT sensor is located on the rear side (The inner side) of the right hand air filter box (See picture below).
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- **Kawasaki VN1700 Vulcan**

