



Installation

Model specific instructions

For:

- **Suzuki AN650 Burgman**
(2003 and up) (K3 models and up)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
- The AIT sensor is located in the left hand side of the air filter box (See picture below).
- Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- **Suzuki AN650 Burgman**
(2003 and up) (K3 models and up)

