



Installation

Model specific instructions

For:

- KTM 1190 RC8
- KTM 1190 RC8 R

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- The Sensor is located in the bottom of the air filter box, just behind the steering head.
- You need to remove the air filter box to install the BoosterPlug.
- The 10 minutes BoosterPlug installation claim does probably not hold on the RC8 and RC8R - it does take some time to remove the air filter box, but race bikes was never made to please the mechanic

Pictures

For:

- KTM 1190 RC8
- KTM 1190 RC8 R

