



# Installation

Model specific instructions

For:

- KTM 990 Adventure
- KTM 990 Adventure R
- KTM 990 Supermoto
- KTM 990 Supermoto R
- KTM 990 SMT
- KTM 990 Super Duke
- KTM 990 Super Duke R

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- On the 990 Adventure, you must remove the fake tank cover between the two gas tanks to get access to the AIT sensor
- On the Supermoto, the SMT and the Super Duke you must remove the gas tank to access the AIT sensor.

## Pictures

For:

- KTM 990 Adventure
- KTM 990 Adventure R
- KTM 990 Supermoto
- KTM 990 Supermoto R
- KTM 990 SMT
- KTM 990 Super Duke
- KTM 990 Super Duke R

