

Installation

Model specific instructions

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

For:

KTM Duke 790

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed. (The red circle)
- The AIT sensor is located in the top of the air filter box.
- One of the connector cables is made longer than seen in the webshop pictures to allow you to relocate the square BoosterPlug
 module as there is not much room around the AIT sensor in the top of the air box.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

