



Installation

Model specific instructions

For:

- [Triumph Thunderbird 1600](#)
- [Triumph Thunderbird 1700](#)
- [Triumph Thunderbird Storm](#)
- [Triumph Thunderbird Commander](#)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the left hand side cover to get access to the AIT sensor.
- These are probably the easiest bikes to install the BoostePlug on :-)

Pictures

