



Installation

Model specific instructions

For:

- [Triumph America EFI](#)
- [Triumph Speedmaster EFI](#)
- [Triumph Bonneville EFI](#)
- [Triumph Bonneville T100 EFI](#)
- [Triumph Scrambler EFI](#)
- [Triumph Thruxton 900 EFI](#)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- **Bonneville, Scrambler, Thruxton**
 - Remove the right hand side cover to access to the AIT sensor in the right hand side of the air filter box.
- **America, Speedmaster**
 - Remove the seat to access the AIT sensor in the top of the air filter box.
- These are probably the easiest bikes to install the BoostePlug on :-)

Pictures

For:

- [Triumph Bonneville EFI](#)
- [Triumph Bonneville T100 EFI](#)
- [Triumph Scrambler EFI](#)
- [Triumph Thruxton 900 EFI](#)



For:

- [Triumph America EFI](#)
- [Triumph Speedmaster EFI](#)

