



# Installation

Model specific instructions

For:

- **Yamaha XVS 1300**

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

## Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
- The AIT sensor is located on the left hand side of the bike, between the head light and the steering head.
- The External sensor on the BoosterPlug is already in the right spot, so you just need to secure it with a zip-tie to avoid it from flopping around.

## Pictures

For:

- **Yamaha XVS 1300**

