



Installation

Model specific instructions

For:

- MV Agusta Brutale 920
- MV Agusta Brutale 990
- MV Agusta Brutale 1090

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed. (The red circle)
- The AIT sensor is located in the top front of the air filter box.
- You must remove the small cover around the ignition lock to access the AIT sensor.
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- MV Agusta Brutale 920
- MV Agusta Brutale 990
- MV Agusta Brutale 1090

