



Installation

Model specific instructions

For:

- **Ducati Panigale V4 (All)**

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
- The AIT sensor is located inside the fairing, in the top of the air resonance chamber.
- Route the external sensor to a spot under the heat light and secure it with a zip-tie so it's not flopping around.

Pictures

For:

- **Ducati Panigale V4 (All versions)**

