



Model specific instructions

For:	
•	Honda FJS400 Silver Wing
•	Honda FJS600 Silver Wing

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

## **Installation Tips**

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- The AIT sensor is located in the rear end of the air filter box.
  - You have several choices for the BoosterPlug sensor location, but our favorite place next to the airbox snorkel air intake hole.
  - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

## **Pictures**

## For:

- Honda FJS400 Silver Wing
- Honda FJS600 Silver Wing

