



Installation

Model specific instructions

For:

- KTM Duke 125 (2011 - 2016)
- KTM Duke 200 (2012 - 2016)
- KTM Duke 250 (2015 - 2016)
- KTM Duke 390 (2013 - 2016)
- KTM RC 125 (2014 - 2016)
- KTM RC 200 (2014 - 2016)
- KTM RC 250 (2015 - 2016)
- KTM RC 390 (2014 - 2016)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed. (The red circle)
- The AIT sensor is located in the upper right hand side of the throttle valve housing.
- Remove the seat and the plastic panels around the gas tank
- Lift the gas tank to get access to the AIT sensor
- You have several choices for the BoosterPlug sensor location, but our favorite place is near the steering head or under the head light. Next to the airbox snorkel air intake hole is another very good spot.
 - Just stick to the simple rules in the general installation instructions for placing the external sensor, and you'll be fine.

Pictures

For:

- KTM Duke 125 (2011 - 2016)
- KTM Duke 200 (2012 - 2016)
- KTM Duke 250 (2015 - 2016)
- KTM Duke 390 (2013 - 2016)
- KTM RC 125 (2014 - 2016)
- KTM RC 200 (2014 - 2016)
- KTM RC 250 (2015 - 2016)
- KTM RC 390 (2014 - 2016)

