



Model specific instructions

aha MT	-01		

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The picture below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the two screws on each side of the head light, and lift off the entire head light assembly.
- The AIT sensor is located behind the head light. (See pictures below).
- The External sensor on the BoosterPlug is already in the right spot, so you just need to secure it with a zip-tie to avoid it from flopping around.

Pictures



