

# MONIMOTO 7

works  
with



## EVEN SMARTER SECURITY SYSTEM FOR MOTORCYCLES, ATVs & UTVs



### HOW DOES IT WORK?



#### MONIMOTO ARMS AUTOMATICALLY

When the Key Fob leaves your ride (~100 ft), the tracker arms, ready to detect any movement



#### DETECTS MOVEMENT

The tracker uses LTE-M (LTE Cat-M1), 2G and GPS to track your ride as well as Bluetooth and an Accelerometer technologies



#### CALLS YOUR PHONE

Detects a theft attempt and calls your phone - all in 50 seconds or so



#### SENDS YOUR BIKES' LOCATIONS

Track your bike on the in-app map over 1-5 min. intervals



#### WORKS

#### INTERNATIONALLY

Monimoto 7 uses brand new LTE-M network as well as 2G network and comes with the embedded eSIM card.



#### DIY DEVICE

Easy installation. No professional needed. Batteries and SIM card are included and ready to go



#### COMPLETELY WIRELESS

No wires and no complicated installation. Offers more options to hide the tracker. It also allows to move the tracker from one ride to another



#### BATTERY POWERED

Wired anti-theft devices are easy to remove and drain your bike's battery life. Your wireless tracker's batteries can last up to one year or more



#### WATER AND DUST RESISTANT

The IP65 rating means your tracker can always keep up with your bike



#### DIRECT SUPPORT

All after sales support is done directly through the App. Just download the App and follow the wizard!

### WHAT'S IN THE MONIMOTO 7 BOX?

- **A MONIMOTO TRACKER**  
with 2 Lithium AA 1.5V batteries. The common lifespan of the battery is up to 12 months or more, depending on how often the device will be in "ALARM mode".
- **A KEY FOB**  
with 1 CR2450 battery.
- **EMBEDDED INTERNATIONAL ESIM CARD**  
pre-loaded with 2 months free connectivity.



### ATTENTION!

1. MONIMOTO has only one purpose: prevent the theft of your property. It cannot be used to log your trips itineraries. Tracking will only begin when it detects a possible theft. You will not be able to use your tracker to locate your ride on demand.
2. MONIMOTO uses GPS signals. For best results, install the tracker correctly and run some tests before your final installation.
3. Remote regions may not have GPS or LTE-M coverage, including deserts and mountains

Description	Retail
Monimoto 7 GPS tracker LTE Cat-M1	169
Monimoto replacement Key Fob	29



#### DATA CONNECTIVITY:

2 MONTHS FREE, 36 GBP/ YEAR AFTERWARDS.

Pay through the App, by credit card or Paypal.

LEARN MORE:



monimoto.tracker



channel "Monimoto"

# MONIMOTO 7



## TECHNICAL PARAMETERS

WARRANTY	2-year limited warranty
PROTECTION RATING	Monimoto and the Key Fob both meet IP65 standard, meaning they are protected from dust and against low-pressure water jets, such as a faucet
SIM CARD COVERAGE	Embedded international eSIM card. Works globally in most parts of the world. 36 GBP payment will be needed after a free period of 2 months. E-SIM card will then be activated for 12 months
NETWORK CONNECTIVITY	
2G (GSM) FREQUENCIES (BANDS)	B2, B3, B5, B8
LTE Cat-M1	B1, B2, B3, B4, B5, B8, B12, B13, B18, B19, B20, B25, B26, B27, B28, B66, B71, B85
SATELLITE NAVIGATION	
POSITIONING	GPS, GLONASS + Telit IoT LOCATE
ADVANCED POSITIONING	2G and LTE-M (LTE Cat-M1) cellular towers
OTHER SPECS	
DEVICE WEIGHT	95 g
DEVICE DIMENSIONS	94x61x19mm
BLUETOOTH	Bluetooth Low Energy (BLE). Your smartphone needs to have Bluetooth 4.0, Bluetooth Low Energy or later in order to work with Monimoto device.
MONIMOTO APP	Apps for iOS and Android available. Minimum OS requirements: iOS 9.0 and Android 5.0. Monimoto does not work with Android 6.0.
DEVICE BATTERIES	Monimoto Device is powered by 2 Lithium AA 1,5V 3000mAh FR6 that can last up to 12 months. Operating temperatures -15°C to 60°C (-40°F to 140°F).
KEY BATTERIES	Monimoto Key Fob is powered by a 3V Lithium CR2450 (1 battery) that can last up to 1 year. Operating temperatures -15 to +55°C (-4 to 131°F).



Designed and manufactured in Europe.  
2 years warranty