

# ENDURALAST EDL-BOIGNS



**Electronic Ignition System  
with Crank Mounted Optical Sensor  
Installation Guide**  
*Fits the stock BOSCH Alternator design*

**EME**  
EUROMOTOELECTRICS.COM


**ELEKTRONIK SACHSE MP**

**Made in Germany** 

Your kit consists of a sensor (EDL-PU-64) and a module (either the EDL-310 or EDL-312)

## EDL-BOIGNS Parts Inventory

Item #	Qty	Description
1	1	Trigger Unit
2	1	Ignition Module
3	1	Ignition Module Plug
4	1	8" Cable Ties
5	1	Velcro Patch
6	1	M5x12 Allen Bolts & Washers
7	3	Insulated Ring Connectors
8	2	Insulated Spade Connectors
9	1	Allen Wrench
10	1	Screw Driver
11	16"	Black wire
12	16"	Brown Wire
13	16"	Red Wire
14	1	Wheel Hub
15	1	Timing Wheel
16	6	4" Cable Ties



## Notes & Disclaimers

Please understand that working on 30+ year old motorcycles may require additional work to the wiring not specifically covered in these instructions. These instructions cover the installation of the electronic ignition on BMW motorcycles model years 1970 through 1995. After 1990, BMW changed the wiring to the ignition circuits and it is not compatible with this ignition system without the addition of a relay. Otherwise damage may occur to the Ignition Module and render the emergency kill switch ineffective.

## Prep the Bike

Disconnect the battery and put it on a charger so it is fully charged when the project is complete. Place bike on center stand, flip open seat, and remove tool box. Turn off both fuel petcocks and disconnect the fuel lines. Remove the tank. Remove the front engine cover and starter cover.

## Remove Existing Ignition or Tune Up Contact Points Ignition If Applicable

The original points ignition components on 1970-1978 Airheads (advance unit, points, points plate, condenser and points compartment grommet) can be **left in place as a backup secondary ignition!** If left in place, the points rubbing block, the points contact surfaces, and the mechanical advance unit would wear normally. You may care to accept this, or you can remove the mechanical advance unit, and store in a Zip-loc bag in the bikes' tool kit. Disconnect the coil negative terminal and cable tie it to the new coil negative wire that will be run from the ignition module later in the installation.



To revert back to the stock points system, simply slide the advance unit back on the cam nose if removed. Switch the coil negative wire to the original points setup.

For 1979-1980 Airheads with points or the “bean can”, You can keep it installed as a secondary ignition system. As stated earlier, it will continue to wear. Alternatively the entire bean can unit is removed by disconnecting the cable going to the condenser mounted on the “bean can”, removing the two bolts on each side, and installing a cover plate.

The points really aren't necessary any longer, they can be removed completely.



For later models with electronic ignition, remove the ignition control unit, located on the right side of the frame just back from the coils.



There are two wire harnesses leading to the stock ICU. The cable connected to the white three plug connector has a green and yellow wire which is a **switched power source**. Use this green and yellow wire from this connector later to trigger the relay detailed on page 16 of this guide.



## Install Cover Plate (optional)

A cover plate can be ordered from Euro Moto Electrics, Part # BMW-COVER to replace the "Bean Can" on 1981-1995 models. Remove the two M5 5mm Allen bolts, pull off the bean can and fit the cover plate. Secure with the original two M5 bolts.



## Remove / Disconnect Non-Stock Ignition Components Ignition (1978-80)

Remove any points amplifiers (also called "points boosters") from the system. These will normally be found zip-wrapped to the motorcycle frame under the tank. Equally, if your engine has been upgraded to an older generation electronic ignition, usually Boyer or Dyna, remove it completely. They cannot be used with the EnDuraLast Electronic Ignition. *If you are not thoroughly familiar with the history of your Airhead, you may be surprised that these were installed by a previous owner.*



Accel units were popular in the 1970s.



Dyna III is a contact points replacement, still using the original mechanical advance.



The Dynatek DBR-1 is the most commonly used points amplifier on Airheads today.



Boyer Micro Digital (Formerly MkIII)

Your new EnDuraLast Electronic ignition is superior to these older units in every way: more robust modern construction, better ignition curves, and crank-driven to avoid the vagaries of cam-driven timing.

## Install Wheel Hub on Rotor Bolt

With a 6mm Allen wrench, remove the center bolt holding the Bosch rotor to the crankshaft. Often this can be removed by “jerking” the wrench without holding the motor from turning. *If the bolt won't break loose, place the transmission in gear and apply the rear brake. This will keep the engine from turning.*




Loosely assemble the timing wheel on the wheel hub, so the wheel 5 mm Allen bit to 14 ft-lbs (168 inch-lbs) with a small amount of thread lock (Loctite blue). Do not over tighten! Our experience shows the existing bolt length is sufficient.



## Install Optical Pickup

The trigger unit is typically installed under the W,V,U connector. Remove the two screws that hold the W,V,U connector and lift to allow enough room for the ignition sensor to slide under the W,V,U (3-phase) Connector




We suggest installing the outer most screw first, then rotate the assembly in place so the disk is seated in-between the pickup slot. Tighten the two M5x12 Allen Bolts (You can use a small amount of thread lock fluid provided if desired.)



Be sure the trigger disk does not touch the brush holder or light pickup and is centered in the light pickup's slot.

## Route Trigger Harness

The ignition module wire can be routed either in the front (diode board side) or back (starter lead side) grommet of the timing chain cover. The front grommet is a much tighter fit and runs the risk of pinching the ignition module wire harness. The back grommet allows much more room for the ignition module lead.



The rubber grommet is already molded for a second wire on 1980 and later bikes; it just needs to be carefully removed and then with a sharp knife cut open to accommodate the trigger wire.



Should the grommet need replacing, both styles are available from EME.

## Install The Ignition Module

Two Ignition Module's are available with this system. Fitment is the same for either module. The only difference is the additional tach or rev wire on the EDL-312 module.

EDL-310



EDL-312



## Mount Ignition Module

The Ignition Module is attached to a suitable surface, which should not be in the splash-water range, with the included Velcro. This should be sufficient, however large cable ties are included for additional support. The wires from the pickup should be long enough to reach almost any desired location. One recommended location on early Airheads is where the large mechanical voltage regulator has been updated to the modern solid state slim version, the top of the voltage regulator works perfectly!

Alternatively, towards the rear of the center frame is often a good location as shown on this R100RS.



**NOTE:** Do NOT install the ignition module inside the alternator cover. The ignition module is sensitive to extreme heat and can be damaged if installed under the alternator cover. Do NOT shorten the pickup leads going to the module - Simply secure any extra wire with cable ties.

## EDL-310 3 Curve Ignition Module

Wire the ignition module as detailed below. Be sure to note the orientation of the plug and the terminals in the correct order.

1. **Ignition Coil Negative Black Wire (-)**
2. **Negative Ground Brown Wire**
3. **Brown Sending Unit Wire**  
(Trigger Ground)
4. **Yellow Sending Unit Wire**  
(0V/5V Trigger Output)
5. **White Sending Unit Wire**  
(+5V Trigger supply voltage)
6. **Power Supply Ignition Positive Red Wire (+)**  
(12V Key ON Power Supply, *Coil Positive is a good source*)



Do not shorten the pickup lead! Tin the end of the wires supplied in the kit with solder when securing into the ignition module plug. If you power the unit while wired in reverse the module will be damaged voiding the warranty and a replacement must be purchased.

### Step 11-A: Set Dip Switches


The Dip Switches are found on the rear of the module. Select the appropriate advance curve for your installation. *Note the module is NOT preset.*

- **Curve 1** has a quicker advance as RPM's increase and top at 34° advance. For **STOCK** single plugged heads.
- **Curve 2** has a quicker advance as RPM's increase and top at 28° advance. For modified **DUAL** plugged heads
- **Curve 3** has a slower advance as RPM's increase and top at 32° advance. Curve #3 is in the middle and, depending on the engine and total setup, might also work for dual plugged heads.

Dip switch positions

1	2	
Off	Off	Module test mode
On	Off	Advance Curve 1
Off	On	Advance Curve 2
On	On	Advance Curve 3





## EDL-312 9 Curve Ignition Module

Wire the ignition module as detailed below. Be sure to note the orientation of the plug and the terminals in the correct order.

1. **Ignition Coil Negative Black Wire (-)**
2. **Negative Ground Brown Wire**
3. **Brown Sending Unit Wire**  
(Trigger Ground)
4. **Yellow Sending Unit Wire**  
(0V/5V Trigger Output)
5. **White Sending Unit Wire**  
(+5V Trigger supply voltage)
6. **Output for an electronic Tach / Rev Counter**
7. **Power Supply Ignition Positive Red Wire (+)**  
(12V Key ON Power Supply, *Coil Positive is a good source*)



Do not shorten the pickup lead! Tin the end of the wires supplied in the kit with solder when securing into the ignition module plug. If you power the unit while wired in reverse the module will be damaged voiding the warranty and a replacement must be purchased.

### Step 11-B: Set Dip Switches

DIP Switch's and the Rotary switch are located on the end of the ignition box. Dip Switch 1 is your over speed protection. Dip Switch 2 should be set up for your tach frequency requirement for either crankshaft or camshaft frequency. The Rotary switch is used to select the desired advance curve.

*(See advance curve illustration to the right.)*


Dip switches

- 1 Over speed protection
  - switch down: 7900 rpm
  - switch up: 8700 rpm
- 2 Rev. counter output frequency
  - switch up: crankshaft
  - switch down: camshaft

Rotary switch


- 1-9 Advance curves 1-9
- 0 Module test mode





## Fasten Wire Connectors

Using the Red, Black and Brown wires included in your kit, strip the end and apply solder to "tin" the wire ends. The wires from the pickup are pre-fitted with connectors for the Ignition Module. With the included small screwdriver, insert the correct wire in the correct slot per the diagram for your ignition module.



## Compatible Coils

The Electronic ignition must use a 2.5-3.2  $\Omega$  coil configuration. You can use stock BMW ignition coils used on models using points and condensers.



When stock Airheads and dual plugged Airheads use two coils wired in series, each of these coils needs a primary resistance of 1.25 to 1.6  $\Omega$  = 2.5 to 3.2  $\Omega$ .

Examples of Compatible Coils

Two recommended replacement coils are:

BOSCH 6V 1.5  $\Omega$  "Super" coils.

**EME Part # BO-Coil6Vx2**

Or

The EnDuraLast 3  $\Omega$  coils


**EME Part # EDL-Coil3.0 $\Omega$**



## Incompatible Coils

The EME ignition is NOT Compatible with conventional electronic ignition coils, which typically have a primary resistance of around 0.7  $\Omega$ . These coils will damage ignition module.

*The DC1-1 (green coil) is compatible with Single Plugged Engines, BUT not compatible with Dual Plugged Engines because that would bring the total resistance to 6.0  $\Omega$ .*



Examples of Incompatible Coils

See coil compatibility to the Right.

## Single Plugged Engine using 2 Coils Wired in Series (stock configuration)

### Compatible Coils

Stock BMW points & condenser coils from 1970-1980

Black coil BMW # 12 13 1 351 584 Bosch # 0 221 100 022 (/5)

Black coil BMW # 12 13 1 243 452 Bosch # 0 221 101 003 (/6,/7, early 100)

Black coil BMW #: 12 13 1 244 142 & 02-21 100 028 (R80RT,R100/

T,CS,RS,RT)

C - Bosch Super "Blue" 6V single tower coil (NLA)

A - Bosch Super 6V single tower coil , Brazilian "silver"

### Incompatible Coils

G - Any coil from any 1981+ BMW motorcycle, Oilheads, Airheads, K-bikes

G - Any coil from a stock BMW transistorized ignition.

## Single Plugged Engine using a Single Two Tower Aftermarket Coil & Single - Plugged Engine using 2, Single Tower Aftermarket Coils in parallel

### Compatible Coils

Accel 140403S 3.0  $\Omega$  dual-tower coil

H - Dyna Dual-tower DC1-1: 3.0  $\Omega$  "Green"

### Incompatible Coils

Accel 140404S 0.7  $\Omega$  dual-tower coil

Dyna Single-tower DC9-4: 0.7  $\Omega$  "blue"

Dyna Single-tower DC10-1: 5.0  $\Omega$  "black"

## Dual Plugged Engine using 2, Two Tower Aftermarket Coils in Series

### Compatible Coils

D - Dyna Dual-tower DC2-1: 1.5  $\Omega$  (wired in series) "brown"

### Incompatible Coils

Accel 140404S 0.7  $\Omega$  dual-tower coil

Dyna Dual-tower DC9-1: 0.7  $\Omega$  "blue"

Dyna Dual-tower DC4-1: 2.2  $\Omega$  "gray"

H - Dyna Dual-tower DC1-1 & DC6-1: 3.0  $\Omega$  "green"

Dyna Dual-tower DC7 & & DC8-1: 5.0  $\Omega$  "black"

Dyna Four-tower DC9-2: 0.7  $\Omega$

## Dual Plugged Engine using 2, Two Tower Aftermarket Coils in Parallel

Compatible Coils None

### Incompatible Coils


Accel 140403S 0.7  $\Omega$  dual-tower coil

H - Dyna Dual-tower DC1-1 & DC6-1: 3.0  $\Omega$  "green"

Dyna Dual-tower DC7 & & DC8-1: 5.0  $\Omega$  "black"

## Coil Wiring on Pre 1986 Models

These models use two identical 6V coils wired together in series with a black jumper wire between the inside terminals - these coils work great with this electronic ignition! Route the Red, Black & Brown wires from the ignition module to the coils and secure with the included cable ties for a clean installation.



The outside terminal of the left coil is the key ON 12 volts and has a green wire that comes from the ignition switch. Connect the RED wire from the module to this terminal to provide power to the ignition system.

The outside terminal of the right coil is the “trigger” connection via a black wire that comes from the condenser under the front engine cover. Replace the BLACK wire on the right coil going to the condenser with the black wire from the electronic Ignition box. *Models with electronic tachometers will have a second black wire connected here. If the original contact point ignition was left in place, these two wires can be switched to revert back and forth from points ignition to upgraded ignition.*


Connect the BROWN wire to either the right or left coil mounting bracket front bolt. (There may be other grounding wires there).

If the bike has aftermarket dual tower coils ( EnDuraLast, Dyna, etc.) note that these coils do not have polarity. Meaning you will assign one terminal to be positive and the remaining assigned negative.



The assigned positive terminal has switched power (green/blue wire) from the chassis harness and the RED wire to the ignition module.

The remaining terminal is assigned to be negative and is the trigger BLACK wire from the ignition module, Feed for a digital tachometer, and were the original contact point condenser would be changed if reverting back to points.



If the engine has been dual-plugged, dual tower coils will take the place of the original BOSCH coils. They are wired the same, with a jumper between them and a switched power (green wire) and trigger (black wire).as illustrated earlier.

## Coil Wiring on 1986 to 1990 Models

Post 1986 models had a single Dual Output Bosch 0.6  $\Omega$  coil which is **not compatible** with this ignition system. It must be replaced with any of the recommended dual tower 3  $\Omega$  coils as described earlier.

The ideal coil is the EnDuraLast dual tower 3  $\Omega$  coil. EME also offers a coil bracket to aid in mounting the replacement coil in the same location as the original coil. This coil (and Dynatek coils) do not have specified polarity. You assign one terminal as positive, and the other as negative



On the assigned positive terminal, connect the red wire from the ignition module along with the original green key ON 12v power.

*There were some variations on later models where the green wire became a green/blue.*

On the assigned negative terminal, connect the black wire from the ignition module. *For bikes with electronic tachometers, there is a second black wire at the trigger connection. Some wiring schemes had two green wires at the switched power connection as well.*

Connect the BROWN wire to a common chassis ground, where other brown wires from the chassis harness are grounded.

## Coil Wiring on Post 1991 Models

After 1990 BMW changed the wiring to the ignition circuit. The power to the Ignition Control Unit is switched separately by the Emergency Kill Switch, while the key still switches the power to the ignition coils.





Additional wiring and a SPST 12 volt 50 amp relay is required. This can be sourced from EME or your local auto parts retailer, and is configured to retain the functional use of the Emergency Kill Switch.

- Connect relay terminal **#86** to the **green/yellow** striped wire that was connected to the original ignition control unit, and the **Red** wire from the Ignition Module
- Connect relay terminal **#85** to a good frame ground terminal.
- Connect relay terminal **#30** the original **green** “switched” wire of the ignition coil
- Connect relay terminal **#87** to the ignition **coil positive** terminal.
- Connect the **Black** wire from the ignition module to the **coil negative** terminal.

With the key switch ON and the kill switch in the ON or run position, there will now be power to the Ignition box and the relay will be energized.

By switching the kill switch OFF, the power is cut to the relay, Ignition module, and the coil.



## Turn The Crank to Top Dead Center (TDC)


Rotate the crankshaft so that the pistons are at top dead center (TDC), the highest point in their travel in the cylinders. Both cylinders on an Airhead have the same TDC crankshaft position.

The timing marks are stamped on the flywheel and viewed through the timing hole to the right of the dip stick.



There is a groove stamped into the left side of the timing hole. This groove is used to align timing marks, NOT the center of the hole.

Rotate the engine by putting the transmission into 2nd gear and bumping the rear wheel around. This is preferred over using an Allen wrench in the alternator rotor bolt to turn the crankshaft as this can wallow out the Allen bolt hole. Turn the crank until the OT dot, to the left of the "OT" stamping on the flywheel, is exactly adjacent to the groove in the timing hole. (OT, in German, is Oberer Totpunkt, literally the "top dead point".) In the event you are having trouble turning the engine over, the spark plugs can be removed but this isn't usually necessary.



The apparent alignment of the flywheel timing marks with the groove on the engine can vary by several degrees by raising or lowering your head a few inches.

This is due to the viewing angle problem if your eyeball is not exactly perpendicular to the timing hole. The problem is worse on R65s which have a 20 mm smaller diameter flywheel that sits even farther from the timing window.

## Airhead Timing Marks

1970 - 1990 BMW Airheads have three timing marks stamped on the flywheel:


- OT: Top Dead Center used for adjusting valves & Ignition timing.
- S: Static Ignition timing, Spaetzuendung, minimum or retarded advance. This is the timing mark to use when timing with the engine off or at idle.
- F: Fast ignition timing, Fruehzuendung (spark advanced), the maximum ignition advance. On later engines, the letter "F" was changed to a "Z".

The horizontal line above the "S" and the dot above the "F" are the actual marks to use for timing. Some flywheels have two lines, one above and one below the timing letter. These indicate the permissible "range" of the timing,  $\pm 3^\circ$  due to "split images", i.e., the difference in timing between the right and left cylinders. Turning the engine over, peering into the timing window, the flywheel will appear to be moving down. From the perspective of a rider sitting on the motorcycle, the flywheel, crankshaft, rotor, camshaft and timing wheel all turn counter-clockwise.

When viewing the flywheel with a stroboscopic ignition light, the "S" horizontal line should appear at idle. As the RPM is increased, the "F" dot mark will slowly move up from the bottom into the window. It will stop moving up at about 2200 – 3800 RPM, depending upon model.

Rarely there may be a flywheel installed incorrectly on the crankshaft (being some multiple of  $72^\circ$  off) so all timing marks are in the wrong place. Re-install the flywheel correctly by installing the flywheel on the crank at TDC (pistons fully extended) with the "OT" mark in the timing window. Flywheels that have been lightened and/or balanced may also have had the timing marks machined off the flywheel. Put them back by measuring the distances from OT to the "S" and "F" marks from the chart on the next page.


The Circumference of all 1970-1980 Airhead flywheels is the same: 736.6 mm. So  $1^\circ$  of crankshaft rotation corresponds to 2 mm (2.046 mm actually) on the flywheel. The only exception to this is the R65 flywheel, which is 200 mm smaller in diameter.  $1^\circ$  of rotation of an R65 crank corresponds to 1.5 mm on the clutch carrier (flywheel).



## Set the Static Timing

Avoid bright light during the adjustment and while driving without the front engine cover installed. The optical sensor can be affected by daylight or very bright shop light(s) and throw off the ignition timing. For example if you take the bike for a test ride without the front engine cover on and round a corner into direct sun, the ignition will more than likely stop functioning.

Turn ignition key to ON. With the engine at TDC rotate the timing wheel clockwise as viewed from the front of the engine. As the wheel rotates, the LED on the trigger plate toggles when the gap is sensed by the light sensor. It will extinguish when the steel flange on the wheel passes the trigger. Rotate the wheel a few revolutions to see how this works.



Slowly rotate the wheel until the LED just turns OFF. Tighten the 2 set screws very tightly. This will get the timing very close and allow you to start the bike. Delay applying the included loctite until you are able to verify the advance with a timing light detailed on page 23.

*NOTE: Rotating the wheel to the right - Clockwise when viewed from the front - will advance the spark.*

*Rotating the wheel to the left -Counter Clockwise when view from the front - will retard the spark,*

*This moves the entire advance curve on the graph up or down when advancing or retarding the ignition timing on the crank with the trigger wheel.*

## Set Full Advance

The amount of ignition advance built into 1970-1980 BMW Airhead motorcycles was determined by the automatic advance unit or “ATU”. These varied during Airhead production as emission controls were introduced. The amount of advance built into the mechanical advance matched the timing marks stamped on the flywheel. For example, if an ATU had 25° degrees of advance, the distance on the flywheel between the “S” and “F” marks corresponded to 25° degrees of advance.

The 1970-1978 ATUs were primarily set up for power. The 1979-1980 canister models were retarded for emission control. While the EnDuraLast Electronic Ignition replaces the ATU, we will continue to use the “F” flywheel timing mark for identifying the fully advanced crankshaft position.

Models	Static BTDC	Advance Range	Total Advance	OT – F Distance <sup>2</sup>
Early /5	9° +/- 3°	30° +/- 2°	39° +/- 2°	79.8 mm
Late /5	9° +/- 3°	25° +/- 2°	34° +/- 2°	69.6 mm
Some /6, early /71	6° +/- 3°	25° +/- 2°	31° +/- 2°	63.4 mm
Some Late /6 and /7	6° +/- 3°	28° +/- 2°	34° +/- 2°	69.6 mm
1979 – 1980 (canister)	6° +/- 3°	26° +/- 2°	32° +/- 2°	65.5 mm
1981+ (electronic ign)	6° +/- 3°	26° +/- 2°	32° +/- 2°	65.5 mm

*(1) After Jan 1, 1978, the static timing mark was retarded from 9° to 6° BTDC for better emission control. Most 1978 flywheels were mis-marked, 4 degrees retarded! A service bulletin describes how to time engine with marks at the top of viewing hole. (2) For R65s, reduce the OT – F distances by 78%.*

The above chart can be used to determine the total advance in degrees that the “F” mark on the flywheel corresponds to. It will be one of 31°, 32°, 34°, or 39°. When in doubt, especially for the ambiguous 1971 and 1978 model years, measure the distance between the “OT” dot and the “F” line. Then use the last chart column to identify the total advance represented by the “F” line.

Having determined what the stock flywheel “F” line ignition timing is, should it be used “as is”? Conventional wisdom might say to rotate the timing wheel so the “F” line is adjacent the timing groove in the timing window under a strobe timing light.

This may not be optimal. Early /5s probably had too much advance; the early /6s too little. The “sweet spot” for most single-plugged engines is about 34°, or curve 1.

After a high compression Airhead has been dual-plugged the stock advanced ignition timing point must be retarded. There has been much dialog, testing, and controversy over what the ideal ignition advance curve should be. After 20 years of discussion, the Airhead community consensus is that dual-plugged engines should have idle timing near stock and fully advanced timing of 27° - 28° degrees. For 28° advance select curve 2.

## Step 19: Dynamically Checked Timing

Take note how the F “dot aligns with the groove on the window, not how it aligns in the window. Your groove may be stamped higher or lower in the window!

Attach a strobe timing light to the left coil spark plug wire. Start the engine and examine the timing marks on the flywheel through the timing window. Raise the RPM until the image stops advancing (moving up) the window, around 3800 (3000 on dual-plugged) RPM. Adjustments are made with the engine off.

To set the timing to the original maximum advance value, adjust (rotate) the timing wheel on the rotor so that at 3800 RPM and above the strobe image looks like this:



To set the timing to 34° (whether or not this was the original BMW value), adjust the timing wheel on the rotor according to the flywheel type as below:

Single Plugged Ignition @ 34° Advance					
	31° F Mark Flywheel	32° F Mark Flywheel	34° F Mark Flywheel	39° F Mark Flywheel	
	Dual Plugged Ignition @ 28° Advance				
		31° F Mark Flywheel	32° F Mark Flywheel	34° F Mark Flywheel	39° F Mark Flywheel

## Fine Tuning Ignition Timing

A particular engine's best ignition timing is dependent upon engine compression and fuel octane. The optimal ignition timing is also dependent on exhaust back pressure and whether a "hot" 336" cam replaces a stock "308" camshaft.

These installation instructions use the best timing for the 1970-1990 Airheads. The 34° advance is conservative and will work with no pinging if the correct octane gasoline is used and the combustion chamber doesn't have higher than normal compression from carbonization. On 1981 and later Airhead models, with the lower 8.2 and 8.4 compression ratios, as well as the R50/5, should use 32° for the maximum advance.

The electronic ignition may, of course, be set to any advance value by simply rotating the timing wheel on the rotor bolt. If you know what you are doing you won't need these instructions and the ignition advance can be set to any value. Too retarded timing under heavy load will result in higher exhaust valve and valve seat temperatures. Too advanced timing will result in engine pinging and possible engine damage. Pinging (also known as "detonation" and "knocking") sounds like steel balls being shook in a jar. It is very pronounced on an Airhead.

Significant deviation from the recommended 34° ignition timing value (28° for dual plugged) will eat up both performance and fuel economy.

To determine the absolute optional ignition timing for optimal horsepower on a specific engine, a dynamometer is needed. This may allow a couple of degrees advance beyond 34° to be used. A shade tree alternative is to advance the timing until the engine just begins to ping and then backing off (retarding) 2 degrees. Pinging is best induced under an actual load going up a hill. Lug the engine in a high gear, at low RPM, with wide open throttle, with a warmed up engine, using the lowest octane fuel that will ever be used.

If ignition timing is advanced beyond what is recommended here to increase mileage and/or power with premium fuel, do not use lower octane fuels without returning to stock timing. The engine could be damaged by pinging for an extended period of operation.

## Apply Thread Locking Compound

Now that you are comfortable that the timing is set to your satisfaction, remove each of the set screws one at a time on the trigger disk and apply a tiny drop of the included Loctite thread-lock then re-install before going to the next set screw. There is no reason to remove these screws once the timing is set correctly except to change the engine timing chain. Not securing the set screws with a thread locker can cause one or all to back out and contact the pickup, causing damage and failure.



## Install Front Cover

***Due to the variance in the Bosch alternator frame sizes, clearance between the timing wheel and front alternator cover must be checked. Damage can occur if the timing wheel is interfering with the front cover during engine operation.***

Do **NOT** run the motorcycle with the front engine cover installed without first verifying clearance between the ignition trigger wheel and the front engine cover.

We recommend you apply a thin layer of grease to the high point of the trigger wheel, secure the cover completely then remove and inspect for any transfer of grease, identifying the point of contact. You may also use machinist putty if available.

In the unlikely case where you experience timing wheel interference with the front cover, the inside of the cover will need to be ground down to allow the space needed for the timing wheel to spin freely. This is a relatively thick casting, yet take care not to take too much away in one go and not to grind all the way through the cover. Repeat until you can verify sufficient clearance. Typically at most 1-3 mm is all that is needed to be removed.



## Install Remaining Components

Lastly reinstall the starter cover, tank, and any remaining items removed earlier to restore the bike to a safe working condition.

# TROUBLESHOOTING GUIDE

## Warning

Do not operate the engine with the spark plug caps disconnected from the spark plugs, not connected to anything (ungrounded), or connected to the spark plug but the spark plug not touching anything (ungrounded). **This can damage the coils internally, fry the sensor, and damage the ignition module.**

## Battery Voltage

Using a digital voltmeter, the voltage reading **MUST** be 12.43 Volts or higher. If your battery is over 3 years old, it should be replaced. If your battery has been discharged 3 times or more, it is sulfated and **MUST** be replaced! The ignition module will not operate reliably if supplied less than 12 volts

## Power To The Ignition System

The ignition system and pickup are powered by the RED wire you ran to the module. Verify voltage at this red wire to ensure the system is receiving adequate voltage of 12 volts or higher. The ignition pickup is powered from the ignition module.

## Power to the Pickup

On the pickup circuit board there is an LED light that will illuminate in-line with the signal that is being sent to the ignition module. If this light is turning on and off with engine rotation the pickup is fine. If not verify that the trigger wheel is in-line with the pickup sensor

## Check Secondary Coil Circuit

Remove a spark plug and securely ground the plug threads to a cylinder fin. Position the plug so that it can be seen firing.

Disconnect the black trigger wire on the right coil which goes to the Ignition module. Using a 2' wire with clip leads, clip one end to this terminal. Turn on the ignition and touch the other end of the wire to a cylinder head fin.

Every time you make/break this connection, you should see the spark plug fire. This is what the points used to do: make and break a connection to ground. Repeat for the other spark plug (*or other three spark plugs for dual-plugged engines*) and verify that each spark plug "sparks". If they do, the coils, plugs, wires, and spark plug caps are okay.

## Optical (Light) Issues

It is important to note that the pickup is an OPTICAL pickup. If bright, direct light including sunlight is hitting the pickup the system will not function correctly. Meaning, without the front cover installed, the system could function in the shop, but die once outside.

## Check Primary Coil Circuit

If there is no visible spark at the spark plugs, investigate the coils further. Leave the 2' wire in place (connecting the outer male terminal on the right ignition coil to ground) and connect a voltmeter positive probe to an inside spade terminal of either coil. The voltage should read about 6.5V, half the voltage of the green/blue wire. (After this test remove the wire with clip leads so we don't burn up the coils). If not, the coil is bad (bad primary circuit) or the crimp connections on the jumper wire between the coils are loose.

## Check the Coils

Disconnect all the wires connected to the coils, including the high tension lead. With a multimeter on the ohms setting, measure the resistance between the two spade terminals on each coil. They should measure 2.0 - 3.5  $\Omega$ , this is the primary resistance of the coil. If outside this range, the coil is bad or you are using the wrong coils.

Measure the resistance from each high tension coil tower to either of the male spade connectors. This secondary resistance will be 12-17K  $\Omega$  for stock Bosch coils, 11.5K  $\Omega$  for Accel 140403S coils, and 14K  $\Omega$  for Dyna DC2-1 coils. If any of these measurements are open circuit, short circuit, or too high resistance the coil is bad.

## Check the Ignition Wires, Caps, and Plug Combination;

### Option 1: 5K $\Omega$ caps with NON resistor plugs.

Measure the resistance end-to-end of the wire/spark plug cap combination. It should be approximately 5K  $\Omega$ . A NON resistor plug must be used in conjunction. Check the part number on the plug, if there is an "R" then it is a resistor plug. This system is known to work well with NGK BP6ES or the NGK equivalent in the appropriate heat range for your particular bike. EME #'s **BMW-WSR18 w/ BP6ES**

### Option 2: 0K $\Omega$ caps with resistor plugs.

Measure the resistance end-to-end of the wire/spark plug cap combination. It should be approximately 0K  $\Omega$ . A resistor plug must be used in conjunction. Check the part number on the plug, if there is an "R" then it is a resistor plug. This system is known to work well with NGK BPR6EIX or the NGK equivalent in the appropriate heat range for your particular bike. EME #'s **BMW-WSR18Zero w/ BPR6EIX**

If the coils, ignition wires and caps check out okay but there still is no spark when the coil negative terminal is grounded, the problem must be the plugs, replace them.

## Check Timing Wheel

Remove the front engine cover exposing the trigger unit. Grasp the timing wheel to check if it is slipping on its hub. If so, the set screws have become loose. Follow the procedures for setting the electronic Ignition timing - when done, secure wheel and use a thread locker.

## Ignition Module Self Test

A self diagnostic test can be run on the ignition module. To run a self test on the ignition module follow these steps:

1. Position the dip switches to test mode (OFF|OFF or DOWN | DOWN for the EDL-310 module, or for the EDL-312 module, point the rotary switch to 0.)
2. Pull one spark plug and reinsert into the plug wire cap. Ground the plug on the head so you can see the spark plug electrode.
3. Turn the ignition key ON - but DO NOT START the bike to supply power to the ignition system.
4. A faint rapid spark will be seen verifying they system is in good working order and the self test has passed

If the spark plugs do indeed spark, the ignition module is not the issue making the optical sensor suspect.

## Pickup Test

With the front engine cover removed so you can view the pickup, turn over the engine with the starter. The LED on the trigger should turn on and off as the timing wheel passes.

- If the LED turns on and off correctly and there is still no spark, the issue is not the pickup.
- If the LED never turns off, loosen the set screws on the timing wheel and slide it in or out slightly on the hub to better align the Hall sensor with the magnets in the timing wheel. If the LED cannot be made to turn on and off the trigger unit is defective.
- If the LED never comes on, check there is at least 12 volts supplied to the red wire going to the ignition module.

## Replacement Components

All components are tested in Germany prior to shipping. Incorrect installation, or using non-compatible components can cause the components to fail. Replacement components are available from the EME Website.

- Replacement Modules are **EDL-310 or EDL-312**
- Replacement Pickup is **EDL-BoignsPU**
- Replacement Trigger Assemblies are **EDL-BoignsTW**

## **IMPORTANT:**

Use only compatible components with this system;

- 3  $\Omega$  coil configuration.
- NON Resistor spark plugs in conjunction with 5K $\Omega$  plug wire caps (BMW-WSR18 w/ BP6ES)

**OR**

- 3  $\Omega$  coil configuration.
- Resistor spark plugs in conjunction with 0K $\Omega$  plug wire caps (BMW-WSR18Zero w/ BPR6EIX)

# ***ENDURALAST***

Euro Moto Electrics

2505 W 2nd Ave Unit # 15 | Denver, CO 80219 USA

[www.euromotoelectrics.com](http://www.euromotoelectrics.com)